

#### **DEUTZ Serial Number Cross-Reference Guide**




# Serial Number cross-reference guide


#### **Contents**


Air-Cooled engines	Page 2 - 13
Family 909	••••• Page 2
Family 910	Page 3
Family 411/511	••••• Page 4
Family F2L912	••••• Page 5
Family 912/913	••••• Page 6 - 8
Family 914	••••• Page 9 - 11
Family 413 F/W	Page 12
Family 513	Page 13
Liquid-Cooled engines	Page 14 - 26
Family 1008/1008 F	Page 14
Family 2008/2009	• • • • • Page 15
Family 1011/1011 F	Page 16 - 17
Family 2011	Page 18- 20
Family 1012/1013	
Family 2012/2013	Page 23 - 24
Family 1015	• • • • • Page 25
Family 2015	




#### **Engine D909L01**







The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is located on the crankcase. The serial No. D is also stamped on the engine block.




## Engine D910L02

Diesel engine


910 ► Engine family

Cylinders in In-line configuration


**02** ► Number of cylinders








The model type A and the engine serial No. B are given in the engine identification rplate.




The engine identification plate C is located on the crankcase. The serial No. D is also stamped on the engine block.



#### **Family 411/511 Engine F2L511W**





The engine identification plate 1 is mounted to the crankcase.

The serial No. 2 is also stamped

into the crankcase.



#### Family F2L912 Eng

**Engine F2L912W** 


F High speed, compact engine

Number of cylinders


L ► Air-Cooled

912 ► Engine family


Indirect injected for underground operation







The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate is mounted to the crankcase.



### Family 912/913 Engine F6L912W

F High speed, compact engine


Number of cylinders

Air-Cooled


Engine family

Indirect injected for underground operation





The model type A and the engine serial No. B are given in the engine identification plate.




The engine identification plate C is mounted to the crankcase.




#### Family 912/913 Engine BF6L913C

Turbo
Highspeed, compact engine
Number of cylinders
Air-Cooled
Engine family
Charge Air Cooled






The model type A and the engine serial No. B are given in the engine identification plate.




The engine identification plate C is mounted to the crankcase.




### Family 912/913 Engine GBF6L913C





The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase.



#### **Engine BF4L914**


B Turbo

Highspeed, compact engine


4 Number of cylinders

L Air-Cooled


**914** Engine family







The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase.

The social No. D is also stamped.



#### **Engine TCD914L06**

Turbo


C ► Charge Air Cooled

Diesel engine


**914** Engine family

Cylinders in In-line configuration


**06** ► Number of cylinders







The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase.



# **Engine TCG914L06**

Turbo


C Charge Air Cooled

**G** ► Gas


**914** Engine family

Cylinder in In-line configuration


**06** ► Number of cylinders








The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase.





#### Family 413 F/W Engine F6L413FRW





#### Family 513 Engine BF6L513RCP





The model type A and the engine serial No. B are given in the engine identification plate.




The engine identification plate is mounted to the crankcase at left of the lube filters and in the air cowling. The serial No. is also stamped into

the crankcase at the flange for mounting the oil filters.

#### **Family 1008/1008F Engine BF4M1008F**

B Turbo
F Highspeed, compact engine
A Number of cylinders
M Liquid-Cooled
1008 Engine family
F Further developed



The model type A and the engine serial No. B are given in the engine identification plate.

The engine identification plate C is mounted to the crankcase. The serial No. is not stamped into the crankcase.



#### Family 2008/2009 Engine TD2009L04

T Turbo


D Diesel engine

2009 Engine family


Cylinders in in-line configuration

Number of cylinders






The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the valve covering hood. The serial No. D is also stamped into the crankcase.




#### Family 1011/1011F Engine BF4L1011FT



For integrated cooled engines with air discharge duct the engine identification plate is located between cooling blower housing and air duct.




#### **Family 1011/1011F Engine BF4M1011FL**






### Family 2011 Engine D2011L04i




For integrated cooled engines with air discharge duct the engine identification plate is located between cooling blower housing and air duct.




#### Family 2011 Engine D2011L04W





The model type A and the engine serial No. B are given in the engine identification plate.




The engine identification plate C is mounted to the valve cover.

The serial No. D is also stamped into the crankcase.



### Family 2011 Engine D2011L04\_





Family 1012/1013 Engine BF4M1012\_C

Highspeed, compact engine


**Number of cylinders** 

**Liquid-Cooled** 


1012 **Engine family** 

Integrated cooled


Charge Air Cooled







The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase. The serial No. is also stamped into the crankcase.



Family 1012/1013
Engine BF6M1013MECP

Turbo

Highspeed, compact engine

6 **Number of cylinders** 

**Liquid-Cooled** 


1013 **Engine family** 

Marine


**External Cooled** 

Charge Air Cooled


High out put version








The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate is mounted to the crankcase.



#### **Family 2012/2013 Engine BF6M2012C**







into the crankcase.


tion plate.

Family 2012/2013 Engine TCD2013L064V






The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase.



#### Family 1015 Engine BF6M1015MCP



the crankcase.

The serial No. D is also stamped into the crankcase.


The engine identification plate C is mounted to




tion plate.

#### Family 2015 Engine TCD2015V06

T Turbo
C Charge air cooled
D Diesel engine
2015 Engine family
V Cylinders in V-Configuration
06 Number of cylinders



The model type A and the engine serial No. B are given in the engine identification plate.



The engine identification plate C is mounted to the crankcase.



## Family 2015 Engine TCG2015V06

